

HI !

The team is:
(depend on what it was decided with the booking agency) :

- 2 MUSICIENS : Léa et Greg
- 1 SOUND ENGINEER : Jo

FOR ALL QUESTION ABOUT WELCOMING OR TECHNIC PLEASE CONTACT :

THE BAND :

Léa – 00337 81 70 52 29 -
Greg – 00336 95 31 77 12 -
onerustyband@gmail.com

SOUND ENGINEER :

Jo - 00336 29 62 45 45 – jonathan.penvern3@gmail.com

CONTACT BOOKING :

Kristell Arquetoux
00336 64 80 49 16

1.PARKING

1 van parking spot near the stage to unload the equipment
and 1 safe parking place for after the show

2.BACKSTAGE

A place to refill water and if it's possible some snacks like dry fruit and some beers.

It's very nice if there is a calm place to put some of our stuff, to change clothes, make up and warm up.

3.CATERING AND RESTAURATION

We eat after the show.

4.TO SLEEP

For the room, diferents solutions are appropriate depend on how many we are: :

-For 2 people : 1 double room (Greg et Léa)

-For 3 people :

In the best case 1 double room (Greg et Léa) and 1 single (Jo).

Or 1 big room with 1 bed for two and a bed for one.

5.MERCHANDISING

A table easily accessible by the audience, after the show.

Contact us for more information

THANK FOR ALL!!!

1.ARTIST

GREG : Guitar / vocals Lead / Foot Drum / Harmonica (one man band)

LÉA : Tap dance / vocals backlead / Washboard / Cymbal / Tom / Acrobati

2.STAGE

Stage must be a flat and stable space about 5 meters wide and 3 meters deep or at least 4 meters wide and 2 meters deep.

the visibility on the foot is very important for the tap dance and the one man band, the front of the stage has to be clear, the monitors has to be on each side of the musicians (in case we have no problem to play on the ground)

3. RISERS (on big stage, on small no need)

if it's possible :

1 riser of 2m x 2meters stage right (on wheels).

1 riser de 2m x 2m satge left. (on wheels or not)

4.ELECTRICITY

Two 16 amp sockets on each side of the stage.

5.MIC and CABLES

We provide all the mic, cables and the stands. n case we have stage boxes to patch both of us. we can also provide the mix consol, Soundcraft UI24 + midi controller X touch

6.PATCH

	ONE RUSTY BAND			
	INPUT	Location	MIC	48V
1	KICK IN	Stage right	Beta 52	
2	KICK TRIG	Stage right	DI	48V
3	SNARE	Stage right	SM 57	
4	SNARE TRIGG	Stage right	DI	48V
5	TAMBOURIN	Stage right	AKG C417	48V
6	BASS GUITAR	Stage right	Output DI amp	
7	GUITAR LEFT	Stage right	E609	
8	GUITAR RIGHT	Stage Left	E609	
9	HARMONICA	Stage right	DI	48V
10	WASHBOARD	Stage Left	ND76S	
11	CYMBAL	Stage Left	AKG C417	48V
12	DRUM TOM	Stage Left	E 604	
13	TAP DANCE	Stage Left	DI	48V
14	VOCAL LEA	Stage Left	SM58	
15	LEAD VOCAL GREG	Stage right	SM58	

